











6T40 Internal Part 2

Presented by:
Bill Brayton
ATRA Senior Research
Technician















Welcome To Today's Presentation Sponsored By:

TRANSIEC®





























2016 Webinar Dates		TRANSMISSION
July	5	6T40 Internal 2
July	19	Nissan CVT Internal
August	2	722.9 Internal
August	16	JF613 Internal
August	30	Drivability Diagnostics 1
September	13	Installation 101
September	27	Drivability Diagnostics 2
October	11	Hybrid Diagnostics & Safety



























Any Questions Or Comments Please Send Emails To webinars@atra.com

Any Questions That You May Have During The Webinar Please Feel Free To Text Them In At Any Time

















When you received the email invitation to the webinar, there should be a place to click and download the Adobe (pdf file) of the presentation handout material.

Also there is an icon that you can click on to be placed onto the email list for future webinars. An invitation will be emailed automatically when future webinars are scheduled.

You can also invite a friend.



Seal Aftermarket Products

Simply click on the time zone below to register for the webinar. AEST is Australian Eastern Time zone.

Click HERE for the presentation handout

Eastern Time Zone 12:00PM September 2, 2014


Mountain Time Zone 12:00PM September 2, 2014


Eastern Australia Time Zone 7:00AM September 3, 2014

Central Time Zone 12:00PM September 3, 2014

Pacific Time Xone 12:00PM September 3, 2014

If you have any questions or problems logging in please contact Shaun Velasquez, ATRA Project Manager St webinars@atra.com or call 805 604 2021.





















A = 96mm (10mm head)B = 40mm (7mm head) 6T40 Internal Quick Review

Splitting the case





One of the many differences between the 6T40 and the 6F35 is the computer bolted to the valve body on the 6T40
















Insect the bushing

Stator Bushing 6T40 Internal Inspection **Quick Review**

because there are no sealing rings on the shaft. If this bushing is worn TCC

To test the bushing for wear use a small piece of cellophane tape on the input shaft. Place the stator on the shaft. If the stator goes over the shaft with tape on it the bushing is worn out and must be replaced.
















Grab the input shaft and left the entire gear train out of the case. Set the assembly aside.

















These units have solid sealing rings on the Input drum support. There are a couple of ways to install the new rings depending on your budget.

The factory can be bought on ebay for about 120.00 (recommended).

The alternative is to use a small engine ring compressor tool for 14.00 from the local parts store.
























With the valve body channel casting to the right, the air bleed hole in the piston goes to the top of the case.
















Case Assembly



Install the thrust bearing with

the flat side up





















Case Assembly

2 – 6 Clutch stack up



Install the 2-6 cushion plate and 2 steels and 2 friction plates















Case Assembly

Typically GM does not publish clutch clearances. As we go through this unit and look at clutch clearances we are not so concerned with the exact measurement as much as we are about the correct stack up. If the stack up is wrong the clearance will be wrong.

On the unit we are working on here the clearance was about .059 inch



Here the clearance is checked from the step in the case down to the face of the friction plate.















Load the L&R one way clutch into the case



6T40 Internal

Case Assembly

Low/Reverse stack up clearance

Prior to installing the L/R clutches into the case the clutch clearance can be checked with the clutches stacked on the piston support. There must some clearance here. The measurement here is .058 in,

















Case Assembly

Starting with the pressure plate and ending with the waved cushion plate install the L & R clutch pack into the case. Notice the grind mark made during disassembly. This mark faces the VB channel casting.




















Install the thrust bearing onto the reaction carrier and install the carrier down onto the sun gear/L&R housing.

6T40 Internal

Case Assembly



Install the sun gear thrust bearing onto the planet.

















Case Assembly



Install the sun gear onto the input shaft splines with the ID groove facing up.



Install the input carrier
















Case Assembly


Install the large thrust washer into the planet and the sun gear thrust bearing onto the sun gear. Note: The skirt on the bearing faces up.













Case Assembly




























Case Assembly

Prior to installing the piston housing check the 1,2,3,4 clutch clearance. The clearance here is .040 as measured on our unit. If there is no clearance check for improper stack up.






















Case Assembly

Install the piston housing into the case



Be sure to align the feed holes in the piston housing with the holes in the case



















Case Assembly

Install the 1,2,3,4 clutch assembly



















Install the 1234 retaining snap ring flat side down. The factory manual states " the opening of the snap ring should be installed towards the bottom of the case".



6T40 Internal

Case Assembly

Tap the snap ring at various location to seat it into the groove


















These parts must be installed prior to installing the output

6T40 Internal

Case Assembly































Place the thrust bearing on the case and install the driven gear and the chain.



Case Assembly


















Case Assembly

The diff sun gear splines to the output gear. The thrust bearing rides between the diff and the sun gear.



Large thrust bearing installed on diff housing.














































Case Assembly

Bell housing onto the main case



















Valve body breakdown





Channel plate and separator plate
















Valve body breakdown

Check ball locations

Six Check balls are all .250


















6T40 Internal Valve body breakdown



Identification Table Next Page















6T40 Valve Body Identification Spring Measurements		
1	Manual Valve	
2	Actuator Feed Limit Valve 1.909 X .525 X .053	
3	Clutch Select Valve 1.215 X .369 X .028	
4	TCC Regulator Valve .781 X .254 X .031	
5	Default Override Valve .869 X .235 X .027	
6	3-5-Reverse Clutch Regulator Valve 1.213 X .369 X .028	
7	2-6 Clutch Regulator Valve 1.192 X .369 X .028	
8	1-2-3-4 Clutch Regulator Valve 1.193 X .369 X .028	
9	1-2-3-4 Clutch Boost Valve 1.004 X .318 X .028	
10	L/R and 4-5-6 Clutch Regulator Valve 1.209 X .368 X .028	
11	L/R and 4-5-6 Clutch Boost Valve 1.003 X .317 X .028	

















6T40 Internal Solenoid Assembly/Disassembly



To separate the sol body from plate take out the small # 10 torx bolts. Once the plate of the body comes away from the plate very easily.















Solenoid Identification




















Separator Plate
Part #24267597
If the gaskets in the kit do
not match the plate, best
bet is to go to your local
dear and get a plate. Cost
about \$10.00


















































A = 96mm (10mm head)B = 40mm (7mm head)

Installing the TECHM







Plug the connectors in and install the pan















Thank you for attending todays presentation. If you haven't had one of these units you will soon!















Today's Presentation Sponsored By:

TRANSIEC®

Any Questions?
Thank You For Attending













